

DESIGN C		CB	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED APPROVED		APPROVED //	DRAWING NO. REV. C	
	PH	111	DSI 9055 SHEET 1 OF 2	
DATE			TITLE SCALE	
06.06.07			OPTIONAL SUPPORT ADDITION NTS	
Α		96.11.12	NEW ISSUE	
В	99.01.19 NOW REF'D AS -111A INSTALLATION PER TSR A843			
С	06.06.07 ADD KIT TO CONVERT -111 TO -111A			

DART SERVICE INSTRUCTION

TO AMEND INSTALLATION DRAWING D350-591 REV. D REF. CANADIAN STC: SH92-6 REF. FAA STC: SH967NE

A D350-591-111 KIT MAY BE TURNED INTO A D350-591-111A KIT BY INSTALLING THE DSI-9055-011 KIT. THE DSI-9055-011 KIT ADDS A SUPPORT AT THE FORWARD CROSSTUBE TO STRENGHTEN THE STEP AND REDUCE FLEX. THE DSI-9055-011 KIT IS DEFINED BELOW AND SHOULD BE INSTALLED PER THE FIGURES ON PAGE 2 OF THIS DOCUMENT.

NOTE: THE AN4-20A BOLTS MAY BE SUBSTITUTED FOR LONGER/SHORTER BOLTS OR ADDITIONAL AN960JD416 WASHERS CAN BE INSTALLED UNDER THE NUT TO ENSURE 1.5-4 THREADS IN SAFETY.

QTY	Part No.	Description	
Х	DSI-9055-011	STEP CONVERSION KIT	
2	D2171	CLAMP	
2	D2182W035	CUSHION	
4	D2274	CLAMP PAD	
1	D2362-3	SUPPORT BRACKET	
4	AN4-20A	BOLT	
4	AN960JD416	WASHER	
4	MS21042L4	NUT	

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-0-01

APPROVED

D. SHEPHERD (DE # 02)

DATE: CERT. NO.:


ISSUE NO .:

06.06.07 SH92-6 8/9/10

Copyright @ 1996 by DART AEROSPACE LTD



DESIGN KE	DRAWN BY CB	DART AEROSPACE HAWKESBURY, ONTARIO, CANA	
CHECKED	APPROVED	DRAWING NO.	REV. C
PH	#t	DSI 9055	SHEET 2 OF 2
DATE		TITLE	SCALE
06.06.07		OPTIONAL SUPPORT ADDITION	NTS



Copyright 1996 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.